



## SOSTITUZIONE DELLA PUNTA CENTRALE NEI TRASCINATORI A PUNTA MOLLEGGIATA REPLACING THE CENTER POINT IN A SPRING-LOADED FACE DRIVER

Per sostituire la punta centrale di un trascinatore frontale a punta molleggiata, non sono necessari attrezzi o chiavi.

- Prendere con le mani la punta centrale e farla scorrere assialmente fino ad estrarla dalla sua sede. In caso di necessità, aiutarsi con uno straccio o un paio di pinze per una maggiore presa.

Per introdurre nuovamente la punta centrale:

- Farla scorrere in direzione dell'asse del trascinatore, fino a farla arrivare nel suo appoggio. L'operazione può essere effettuata con il trascinatore già montato in macchina, senza pregiudicare la precisione dello stesso.

*No tools or wrenches are required to replace the center point of a spring-loaded face driver.*

- *Take the center point with your hands and slide it axially until it comes out of its seat. If necessary, help yourself with a rag or a pliers for a better grip.*

*To re-introduce the center point:*

- *Slide it in the direction of the face driver axis, until it reaches its support. The operation can be carried out with the face driver already mounted on the machine, without compromising the accuracy of the same.*

